

**Please read carefully before use and retain for future reference**

## **BEFORE USE**

- Remove all packaging before use.
- Wash before first use and allow to fully dry.

## **WARNING**

- Suitable for use in standard gas, electric or ceramic ovens and induction cookers. Can also be used on a hob for short periods, e.g. to make gravy.
- Oven safe to 220 C/ Gas Mark 7
- Do NOT allow to boil dry as this may damage the ceramic surface.
- Always use oven gloves when handling hot roasters.
- Do NOT cut food whilst it is in the roaster as this could damage the base of the roaster.

## **USE**

- Lightly grease the side and base of the roaster or rack with a little oil to prevent food from sticking,
- Place food onto the rack or into the roaster and cover with the lid. Follow cooking instructions provided from foodstuffs.
- Use the racks to sit food above the oil and fats that are produced during the cooking process.
- To brown, place under grill with the lid removed for a few minutes.

## **CLEANING**

- Always allow to cool fully before cleaning.
- Wash in warm soapy water with a soft non- scratch sponge or cloth, dry fully before storing.
- Do NOT use abrasives or steel wool scourers.
- Leave to soak for a few minutes to soften burnt on foods before cleaning as normal.
- Dishwasher safe
- Always follow dishwasher manufacturer's instructions for use.
- Never leave in the dishwasher to dry, always remove and dry by hand with a soft cloth.
- The roaster may be damaged if exposed to corrosive substances such as dishwasher salt, water softener or detergents for extended periods.

## **Packaging**

- Dispose of packaging at your local recycling centre.
- Dispose of paper and carton separately from plastic bags at your local recycling centre.
- Dispose of this item at the end of its lifespan at your local authorised household waste recycling centre.



