FOR OUTDOOR USE

How to use

1. Make sure that the chair is on a flat surface.
2. Do not put your hands or fingers under the mechanism to operate the chair.
3. To open the chair, hold the top of the backrest of the chair and gently pull out the front of the chair until the frame is open and the chair is in an upright position. Making sure the position is clicked securely in place.
4. Sit down in the chair slowly.
5. To lock in the upright sitting position simply position the locking paddle under each arm rest, to either left or right horizontal position on each side.
6. To recline the chair, sit on the chair with your feet resting on the metal bars at the bottom of the chair and unlock the locking paddles below each arm rest to the vertical position.
Gently lean back until you have reached the desired reclined position.
To lock the position of the chair simply push the locking paddle, underneath both arm rests, to either left or right horizontal position. Check the chair is locked and does not move.

To fold the chair away

1. Return the chair to the upright position.
2. Do no put your hands or fingers under the mechanism to operate the chair.
3. Ensure the locking paddles underneath the arm rests on either side of the chair are unlocked to vertical position.
4. Hold the top of the backrest of the chair and gently pull the front of the chair inwards. The chair will then fold into the closed position.

Warnings

• This chair holds a maximum weight of 100kg (15st 10lb).
• Designed for use by one person at a time only.
• Do not put your hands or fingers under the mechanism to operate the chair.
• Do not stand or jump on the chair.
• Outdoor use only.
• Always ensure that the chair is in a locked position and fully open before sitting on it.
• Always check the chair before each use. Do not use if broken.

Disposal

Dispose of all paper, cartons and plastic in accordance with your local recycling regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.