



WARNING:

- Do NOT use on uneven or unstable surfaces.
- When using the step, step only on the centre. Do NOT step on the edges as this may cause the step to tip or topple over.
- Do NOT jump on the step.
- Do NOT lean from the step when in use. Always dismount and resite.
- This is NOT a toy, children should be supervised at all times.
- Periodically check to ensure the step is located securely and has not moved.
- Maximum weight load limit up to 150kg (23st).
- For use indoors and outside.
- If located outside, take care when the step is wet or icy as although it has drainage holes it may become slippery
- Keep the step clean from mud, snow etc. by wiping with a damp cloth or brush.

Complies with EN14183. Max Load: 150Kgs

PACKAGING:

Dispose of the packaging at your local recycling centre.

Dispose of paper & box separately from plastic bags at your local recycling centre.

Dispose of the item at the end of its lifespan at your local authorised householdwaste recycling centre.