Awning Replacement Covers 9407

7 Instructions

PARTS

1x Replacement fabric


6x Fixings (screws and plugs)

3x Cable

REMOVING THE AWNING MATERIAL

Note: Remove the awning frame from the wall before replacing the awning matieral.

- 1. Tie the folding sections of the awning arms together.
- Unscrew the 2x screws that hold the end cap onto the awning bar and remove the end cap. Only remove the end screws and end cap from one end of the awning bar.
- 3. Remove 2x plugs that held the 2x screws that were removed in step 2.
- Remove the end cap from one end of the frame by releasing the clips. Tap with a hammer to loosen the bracket if necessary.
- 5. Slide the valance out from the awning bar.
- 6. Unscrew the bolt from the end bracket.
- 7. Pull out the roller from the awning frame.
- 8. Unroll the fabric from the roller.
- 9. Unscrew the 1x screw that holds the fabric to the roller and remove the plug at one end of the roller only.
- 10. Slide out the fabric from the roller at the open end.























Conners


REPLACING THE AWNING MATERIAL

- 11. Feed the cable through the loop at the end of the replacement cover for the awning at both the top and bottom. Repeat for the bottom of the valance.
- 12. Slide the back into the roller along the groove, replace the plug and tighten the screw.
- 13. Roll up the replacement awning cover, ensuring the fabric is correctly aligned.
- 14. Slide the fabric into the awning bar, ensuring the fabric is correctly held in position.
- 15. Slide the valance into the awning bar, ensuring the seam is on the inside.
- 16. Slide the roller into the holders at both ends of the frame.
- 17. Screw the bolt into the end bracket.
- 18. Re-attach the end cap to the frame ensuring the clips lock into position.
- 19. Replace the plugs and re-attach the screws.
- 20. Untie the awning arms.

DISPOSAL

• Dispose of all paper, cartons and plastic in accordance with your local recycling regulations.


At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.







13.











19.



12.





16.



18.



20.