

**Batteries:**

Requires 2x 1.5V AA batteries (not included)

Motor voltage: 3.0V DC

Approximate run time: 2 hours (per battery pair)


Cleaning capacity: 2.5 tablespoons.

Please read this instruction manual thoroughly before starting and ensure you are familiar with the operation of your new battery powered Copper Crumb Vac.

For cleaning up small, dry particles and debris from hard and upholstered surfaces such as: countertops, desks, tables, tile and wood floors, low to moderate pile carpeting, sofas, chairs, beds, blankets, leather surfaces, car interiors, bags and suitcases.

**Operation****Installing Batteries:**


1. Open upper dome housing by rotating it counter-clockwise. Indicator line on edge of dome housing should move from "CLOSE" to "OPEN" (See Fig. 1)
2. Install 2x 1.5V AA batteries following the indicated polarity (see Fig. 2)
3. Replace upper dome housing.
4. Run the copper crumble over the crumbs to be vacuumed.

**Turning ON/OFF**

1. Use thumb or finger to slide power switch located on the side of the unit from "OFF" to "ON".

Emptying/Cleaning

1. Remove base cover by pressing tab labelled "PUSH" while tilting base cover downward to separate it from upper housing (see Fig. 3).
2. Remove filter assembly by simply pulling it out of upper housing. It will "snap" free to expose the motor turbine.



MAINTENANCE:

1. Empty debris particles from the base cover into the waste bin after each use for best performance.
2. Completely remove base cover and filter assembly from unit for cleaning. Rinse base cover and filter under warm water to clean leftover particles and residue. Make sure cover and filter are completely dry before reassembling.
3. Do not expose upper housing or motor components to water. These components should be cleaned using only compressed air or a small brush if needed.
4. If a decrease in cleaning performance is noticed, empty base cover, check for blockages, and replace batteries if need be.

BATTERIES:

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

