

Part List



Dimensions:

30cm *30cm* 99cm

Weight: 4kgs

Material:

Steel with black paint



Metal surface can get extremely hot.


Part List	Description	Qty.	Drawings
A	Rain Lid	1	
B	Top Left and Right Panels(with hole)	2	
C	Top Front and Back Panels (without hole)	2	
D	Top Corner Pieces	4	
E	Bottom Side Panels	4	
F	Bottom Base Panel	1	
G	Top Connecting Bar	1	
H	Base Corner Pieces	4	
I	Bolts M6*8	42	
J	Nut	1	
K	Allen Wrench	1	
L	Top Support Bar	1	

Tools required: Allen Wrench (provided), Adjustable Wrench (not provided)


DO NOT overtighten hardware.

Step 1:


Place parts on a smooth level surface.
 Attach 3x Bottom Side Panels (E) to Base Corner Pieces (H) by using Bolts (I).
 Hand tighten!

**Step 2:**

Insert Bottom Base Panel (F) into assembled Step 1 base. Attach the last piece Bottom Side Panel (E) to Base Corner Pieces (H) by using Bolts (I). Hand tighten all hardware and make sure all pieces fit together securely.

**Step 3:**

Connect 4x Top Corner Pieces (D) with Base Corner Pieces (H) by using Bolts (I). Attach 2x Top Left and Right Panels (with hole) opposite Top Corner Pieces (D) by using Bolts (I), then attach Top Front and Back Panels (without hole) opposite Top Corner Pieces (D) by using Bolts (I).




Step 4:

Attach Top Connecting Bar (G) to 2x Top Left and Right Panels (with hole) by using Bolts (I). Hand tighten.



Step 5: Screw Nut (J) to Top Support Bar (L) and Screw Top Support Bar (L) to assembled Top Connecting Bar (G). Attach Rain Lid (A) to Top Support Bar (L).

Fully tighten all hardware and make sure all pieces fit together securely.

**Positioning**

- Place on a flat fireproof surface (rocks, bricks, paving stones, concrete surface).
- Position clear of overhanging tree branches or bushes and at a safe distance from fences.

Safety

- Only burn small amounts of charcoal and wood.
- Do not use fuel or alcohol to ignite flames.
- Do not extinguish fire with water.
- Keep indoors in extreme cold periods. If unable to keep indoors, in freezing weather, warm up your chiminea before building a fire.
- Use long sleeve oven gloves and fireplace tools to add logs and stoke the fire.

CARE AND CLEANING INSTRUCTIONS:

- Wipe clean with dry cloth.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.