Please read and retain these instructions for future reference

v002: 18/01/23



For artificial lawns



Bristles: Double row super-tough polyamide 40mm filament bristles, each row 97 bristles, 194 bristles in total.

Brush head: high grade polypropylene, 45cm wide sweep area.

Telescopic handle: powder coated steel with ergonomic and easy use twist-grip locking handle. 78cm to 130cm with head attached.

Assembly

Insert the handle in to the brush head until the black locking latch "clicks" into place. Then turn the handle counter clockwise and extend the steel handle to the desired length and lock the handle in place by twisting the handle clockwise.

Reverse the procedure to remove the handle for storage.

Start raking in one corner and work your way across your artificial lawn using brush strokes in the same direction to remove moss, leaves and debris and to invigorate and lift the tuft.



You should use your Fake Rake once a month to ensure your lawn remains in top condition.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.



UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595 www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269

UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.