Deluxe Wood Effect LED Floor Lamp 1031 wo Instructions for Use

Please read and retain these instructions for future reference

v003: 06/03/21


Before you begin:

- Inspect lamp before assembly. Some wire connections have been made at the factory and the lamp is ready for assembly.
- Remove all packing materials from the lamp.
- To prevent bad connections, avoid pulling wiring connections when removing contents from package or during installation.
- Lay out all the parts on a flat surface.

Assembly Instructions:

To prevent damage to the pole, please follow the steps below:

- 1. Take the FLEX POLE and feed the POWER CORD through the UPPER POLE.
- 2. Screw the UPPER POLE clockwise into the FLEX POLE. (Be careful not to pinch the wires.)
- 3. Feed the POWER CORD through the MIDDLE POLE and screw MIDDLE POLE clockwise into the UPPER POLE. (Be careful not to pinch the wires.)
- 4. Feed the POWER CORD through the LOWER POLE and screw LOWER POLE clockwise into the MIDDLE POLE. (Be careful not to pinch the wires.)
- 5. Connect the two ends of the POWER CORD by pressing the LOCK CONNECTORS into place.
- Carefully feed the excess POWER CORD into the LOWER POLE. (DO NOT CUT OR SHORTEN THE POWER CORD).
- 7. Turn and tighten the metal connecting COLLAR onto the base.
- 8. Take out the screw and insert the LOWER POLE into the COLLAR.
- Check direction of the lamp and line up the screw holes and use a screwdriver to tighten the screw.



Deluxe Wood Effect LED Floor Lamp J031 wo Instructions for Use

Please read and retain these instructions for future reference

v003: 06/03/21

- 10. Be careful not to pinch the cord between any metal parts.
- 11. Plug the DC plug into the socket on the base.
- 12. Plug the ADAPTER into outlet and now the lamp is ready for use.

The LEDs are specially formulated to simulate the characteristics of natural sunlight. They are nonreplaceable and should give up to 50,000 hours of use.

50,000 hours

365 days a year

Assume 4 hours use summer time 7pm – 11pm for 182.5 days every day = 730 hours Assume 6 hours use winter time 5pm – 11pm for 182.5 days every day = 1095 hours

Total annual hours: 1825/50,000 = 27 years

Operation Instructions:

The LED Floor Lamp has three different colour settings,

- 6,000K = full spectrum light mode
- 4,500K = soft white mode
- 3,000k = warm-white mode
- 1. Touch the power button to turn on the lamp to the 6,000K colour temperature level which is the full spectrum light mode.
- 2. Touching and holding the power button again will gradually dim the light to its lowest level, then gradually brighten to its highest level and dim back to its lowest. When the dimming feature reaches your desired brightness, release the button.
- 3. Touching the power button again will turn off the lamp.
- 4. If the power button is touched again within 5 seconds the lamp will enter the 4,500K colour temperature level which is the soft-white mode. Touching and holding the power button again will gradually dim the 4,500K light mode.
- 5. Touching the power button again will turn off the lamp.
- 6. If the power button is touched again within 5 seconds, the lamp will enter the 3,000K temperature mode which is the warm-white level. Touching and holding the power button again will gradually dim the 3,000K light colour.
- 7. If the power button is quickly touched repeatedly without holding, the light will rotate between the different colour modes.
- 8. If the lamp is turned on after 5 seconds, the light will go back to the last colour.

TECHNICAL INFORMATION:

LED Class:

Power supply: DC14V, 0.75A

Power output: 12W

Caution:

Do not tilt the lamp head to the left or right of the base to avoid tipping.

Deluxe Wood Effect LED Floor Lamp 1031 wo Instructions for Use

Please read and retain these instructions for future reference

v003: 06/03/21

WARNINGS AND SAFETY INSTRUCTIONS:

- THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE CANNOT BE REPLACED; IF THE CORD IS DAMAGED, THE LUMINAIRE SHALL BE DESTROYED.
- ENSURE THAT YOUR MAINS VOLTAGE CORRESPONDS TO THAT STATED ON THE UNIT.
- USE ONLY THE ADAPTOR SUPPLIED.
- NEVER USE THE UNIT IF ANY PART IS DAMAGED.
- THERE ARE NO USER SERVICEABLE PARTS, IF A FAULT DEVELOPS, THE UNIT MUST BE RETURNED TO THE SUPPLIER FOR REPAIR/REPLACEMENT SUBJECT TO GUARANTEE CONDITIONS.
- DO NOT ALLOW THE UNIT TO GET WET.
- DO NOT ALLOW THE CABLE TO LIE ON HOT SURFACES.
- DO NOT LOOK DIRECTLY AT THE LIT LEDS.
- ROUTE THE POWER CABLE SO THAT IT WILL NOT GET WALKED ON OR PULLED (TRIP HAZARD).
- DO NOT ALLOW CHILDREN TO PLAY WITH THIS UNIT, IT IS NOT A TOY.
- THIS UNIT SHOULD NOT BE USED BY PERSONS (INCLUDING CHILDREN) WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES, OR LACK OF EXPERIENCE AND KNOWLEDGE, UNLESS THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE UNIT BY A PERSON RESPONSIBLE FOR THEIR SAFETY.
- THE UNIT IS NOT INTENDED TO BE OPERATED BY MEANS OF AN EXTERNAL TIMER OR SEPARATE REMOTE-CONTROL SYSTEM.

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and unplug before cleaning.
- Do NOT use polishes or cleaners.
- Wipe surfaces with a soft dry cloth.
- Allow to dry thoroughly before further use.
- Store the appliance in a dry, clean and stable place.


Deluxe Wood Effect LED Floor Lamp J031 wo Instructions for Use

Please read and retain these instructions for future reference

v003: 06/03/21

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Code & Symbol	OTHER
Type of Plastic	Various
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

 At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



