



Warning:

DO NOT FILL WITH WATER.

LED WIRES MUST NOT BE REMOVED FROM INSIDE THE VASE.

Batteries required: 2x AAA batteries
(not included)

Instructions

- Open the battery case located on the bottom.
- Insert 2x AAA batteries (not included), observing correct polarity, as shown inside the battery case.
- Close the battery case.
- Turn the unit on/off using the switch located on the bottom.

CARE AND CLEANING INSTRUCTIONS

- Always switch off before cleaning.
- Do NOT immerse in water. Risk of electric shock.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Wipe surfaces with a soft dry cloth.
- Allow to dry thoroughly before further use.
- Store the appliance in a cool, dry place.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.


DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper,

cartons, packaging in accordance with your local recycling regulations.



- Plastics, polybags – Contains the following recyclable plastic.

Code & Symbol	 PETE
Type of Plastic	Polyethylene Terephthalate
Commonly used for	Soft drink and juice bottles, shampoo bottles, meat trays, fruit punnets
Notes	Commonly recycled and collected from household recycling bins. Check with your local authority

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

