# Lipstick Hair Remover H663 BLK/RE/LEO Instructions for Use

Please read and retain these instructions for future reference


v001: 11/07/22


### **INSTRUCTIONS FOR USE:**

NOTE: Prior to first use, test on a small area. If any sensitivity or allergic reactions occur, discontinue use immediately. Do not use on sensitive or irritated skin.

## **Installing/Changing Battery**


- Remove the cap (Image 1)
- Grab the upper section of the unit with one hand, the bottom half with the other, and pull apart (Image 2) to reveal the battery chamber
- Place 1x 1.5V DC AA battery (not included) into the compartment, making sure the positive pole (+) is facing the bottom of the unit.
- Slide/snap the unit's bottom casing back into place (Image 2)






### How to Use

- Remove the cap (Image 1)
- Slide the gold switch located on the side of the unit upward into the "ON" position (Image 3). The light will automatically turn on when the unit is "ON".
- Gently press the head of the unit flat against your skin. The unit should not be at an angle. Make small circular motions to remove unwanted hair. (Image 5).
- NOTE: It is normal for the head to become warm with use.



### Cleaning (Be sure unit is off)

- Twist the rotating hair removal head counter-clockwise and lift off (Image 4).
- After each use, clean the head by using a brush (included) to wipe away the hair residue.
- Empty any hair from the body of the unit by turning it over and gently tapping the sides.
- To put the hair removal head back on the unit, line up the "groove" indicators on the cap with those on the unit and twist clockwise (Image 4).



# **Tips & Pointers**

- For superior results, use on hair ¼" length or less.
- If the unit begins to slow down, clear the hair removal head and body of any hair residue. If the unit is still running slowly change the battery.
- Gentle enough to use every day.
- For airbrush-like make-up application, use daily.



COOPERS OF STORTFORD

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400\*, Fax: 01279 756595

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269

UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

# Lipstick Hair Remover H663 BLK/RE/LEO Instructions for Use

Please read and retain these instructions for future reference

## **WARNING:**

- Do not use on irritated skin. Discontinue use if skin irritation occurs.
- Exercise caution when using around eyes.
- Do not rinse trimmer head under water.
- Do not submerge unit under water.
- Store in a cool dry place when not in use.

## **BATTERIES:**

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

## **DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



v001: 11/07/22

• Plastics, polybags – This product contains the following recyclable plastic.

Code & Symbol	OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



