



Dimensions

(L) 16cm x (W) 14cm x (H) 31cm

Weight: 470grams (approximately)

Batteries required: (not included)
2x C 1.5V batteries



Attaching the pine cone/bow decoration

Operating instructions

- Remove the lantern from the packaging.
- To attach the pine cone/bow decoration, screw in the hook to the top and then attach the decoration (see above image).
- Insert 2x C batteries into the battery compartment on the bottom of the lantern.
- Close the lid back and make sure it is properly sealed.
- Turn ON/OFF to switch light on and off.
- Turn Timer switch to set the 6-hour timer.

BATTERIES


- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.

- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

