S/3 Whistling Key Finder

G075


Instructions for Use

Please read and retain these instructions for future reference

v002: 24/06/20



Powered by 2 x AG3 batteries (included)



How to use

- 1. Put the key with the key finder.
- Slide the button to the on |.
 position
- If you cannot find your key, just whistle.
- The key finder will alarm and you can find your key.


DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – Contains the following recyclable plastic.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400* Fax: 01279 756 595 www.coopersofstortford.co.uk



COOPERS OF STORTFORD

S/3 Whistling Key Finder

G075

Instructions for Use

v002: 24/06/20

Please read and retain these instructions for future reference

Code & Symbol	OTHER
Type of Plastic	Please Specify (includes ABS, Nylon)
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400* Fax: 01279 756 595 www.coopersofstortford.co.uk



*Calls cost 7 pence per minute plus your telephone company's network access charge