21x29.7



Portable LED Lamp

CAUTION:


- * ALL BATTERIES MUST BE OF THE SAME TYPE AS MENTIONED.
- DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT MIX ALKALINE, STANDARD, OR RECHARGEABLE BATTERIES.
- IF BATTERY CONTENTS ARE LEAKING, DISCONTINUE USE AND DISCARD.
- REMOVE EXHAUSTED BATTERIES.
- REMOVE BATTERIES IF NOT IN USE.


BATTERY INSTALLATION:

- 1. Unsnap the battery cover (located on the base of the lamp).
- Insert 4 AA batteries (not included) matching the polarities inside the battery compartment and replace the battery cover.

*A USB cable is included to power the lamp whenever a USB port is available.

USE INSTRUCTIONS:





- To unfold the lamp simply hold on to the base and pull the lamp head upward.
- 2. The lamp can be adjusted to provide light where needed.
- *The lamp has three levels of brightness, simply press the power symbol to choose the brightness you desire.

