Free Standing Airer

G392

Instructions for Use

Please read and retain these instructions for future reference

v002:06/02/23



Dimensions:

Open Size Is 102x102x138cm

Composition:


Aluminium and ABS

- FREE STANDING SO YOU CAN PLACE IT ANYWHERE
- 4 STURDY LEGS ALSO WITH 4 GROUND PEGS SO YOU CAN SECURE INTO THE GROUND IN WINDIER WEATHER
- NO NEED FOR FIXING OR DRILLING
- GREAT FOR SMALLER GARDENS WHERE ONE FIXED INTO THE GROUND EITHER ISN'T POSSIBLE OR TAKES UP TOO MUCH ROOM AS A PERMANENT FIXING
- 16 METRES OF DRYING SPACE ALL TOGETHER
- EASILY UP AND DOWN, THEN FOLDS FLAT FOR EASY AND COMPACT STORAGE
- WEATHERPROOF

Assembly

1. Fold out base (Fig. 1) and attach metal arm to the plastic hooks on the base (Fig. 2).

Fold out the arms (Fig 3) and place the main pole through the hole in the centre of the stand (Fig. 4).



For added stability ensure an even distribution of washing around the free standing airer. The airer can be left outside, but it is recommended to cover or put into storage when not in use to extend the life of the product.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

