

Solar Peacock Ornament

Item codes: G482

Instructions for Use

v002: 04/12/23

Please read and retain these instructions for future reference

GAINSBOROUGH

Garden & Wildlife



**ALWAYS USE ALKALINE BATTERIES.
DO NOT USE LITHIUM BATTERIES.**

Material: Hand Carved Resin

Size: 17.5*20.5*47.5cm

Weight: 1.6KGS

Battery: 1x AA 1000mAh 1.2V

Solar panel: 2v 300ma

55 x80mm

Non-replaceable LED lights

Please read this instruction manual thoroughly before starting and ensure you are familiar with the operation of your new Solar Peacock Ornament.

How the solar light works:

- During the day, the solar panel converts solar power into the rechargeable battery.
- At night, the light turns on automatically by the stored energy. How long the light lasts depends on its location, weather conditions and seasonal lighting availability.

Choosing the right location

- An outdoor location with direct sunshine and where the solar panel of your light can receive at least six hours of sunshine each day is an ideal location for a solar light.
- Shady locations will influence the batteries charge and may shorten the working time of the light at nighttime. The solar light should not be placed near lighting such as streetlight, which may cause the light to turn off.

INSTRUCTIONS FOR USE

1. Gently remove the statue from the packing and position it in a sunny location with the solar panel facing the sun.
2. Press the switch to the "ON" position to turn the light function on and to charge the battery. Press the switch to the "OFF" position to turn the light function off.
3. For the initial charge, allow the solar panel to charge the battery for a full day for best results. When darkness falls, the solar light will illuminate for several hours (depending on charge).

Troubleshooting

- If the light does not turn on at dusk after 8 hours of charging:
- Ensure that the solar light is in a bright sunny location and not in a shady area during the day.
- Make sure that the light's photocell is not affected by other light sources at night. Clean the photocell regularly.

- Verify that the battery is making contact with the terminal and that it has been inserted in the correct polarity.
- Ensure that the “ON/OFF” button is in the “ON” position.

WARNINGS AND SAFETY INSTRUCTIONS:

WHEN USING ANY APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- FOR DOMESTIC OUTDOOR USE.
- NOT FOR COMMERCIAL USE.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.
- THE USE OF ANY ACCESSORY OR ATTACHMENTS NOT RECOMMENDED BY COOPERS OF STORTFORD MAY CAUSE INJURIES AND INVALIDATE ANY WARRANTY YOU MAY HAVE.
- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- DO NOT COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- DO NOT LEAVE SWITCHED ON OR UNATTENDED.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the battery or cause battery to explode or leak.
- Use the same type, new rechargeable batteries. (USE RECHARGEABLE BATTERIES ONLY).
- Do not dispose of battery in fire.
- Battery should be recycled or disposed of as per local recommendations.
- Remove battery if consumed or if the product is to be left unused for a long period of time.

BATTERY WARNING:

KEEP OUT OF REACH OF CHILDREN. IF SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY SEEK IMMEDIATE MEDICAL ATTENTION.

- INSTALL BATTERIES IN ACCORDANCE WITH ITS POLARITY SYMBOLS. DO NOT FIT BATTERIES IN REVERSE.
- DO NOT SHORT CIRCUIT THE BATTERY TERMINALS.
- REMOVE THE BATTERIES IF LEFT FOR LONG PERIODS.
- **KEEP BATTERIES AWAY FROM CHILDREN AND PETS.**
- DO NOT MIX USED AND NEW BATTERIES.
- **NEVER DISPOSE OF BATTERIES IN A FIRE.**
- BATTERY DISPOSAL, SPENT OR EXPIRED BATTERIES MUST BE DISPOSED OF AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER’S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS.

CARE AND CLEANING INSTRUCTIONS

- ALWAYS SWITCH OFF AND REMOVE BATTERIES BEFORE CLEANING.
- DO NOT IMMERSE IN WATER.
- DO NOT USE ABRASIVE CLEANERS OR SHARP UTENSILS TO CLEAN THIS APPLIANCE.
- WIPE SURFACES WITH A SOFT DRY CLOTH. DRY THOROUGHLY BEFORE FURTHER USE.
- STORE THE APPLIANCE IN A COOL, DRY PLACE
- KEEP THE SOLAR PANEL CLEAN AND FREE OF DEBRIS FOR BEST LIGHTING RESULTS.

Battery Replacement

NOTE: This operation should be done in the morning on a sunny day. This will allow the light to receive a full 8 hours of sunlight so that the rechargeable battery can reach maximum capacity.

- Pull solar top out from the light and turn solar top upside down to access battery compartment.
- Remove the battery compartment cover.
- Note: Clean the battery contacts and those of the device prior to battery installation.

- Be sure to insert the batteries in the proper direction.
- Replace the battery compartment cover.

BATTERY DISPOSAL

- SPENT OR EXPIRED BUTTON CELLS MUST BE DISPOSED SAFELY AWAY FROM CHILDREN ACCESS AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER'S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



CUSTOMER SERVICES:

Distributed by / Verteilt durch / Distribué par.

UK: The Enterprise Department Ltd.
11 Bridge Street, Bishops Stortford, Herts, UK, CM23 2JU
Tel: 0330 331 0300

NI/EU:
D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269

