
# Soothing Sounds Machine G607

## Instructions for Use

Please read and retain these instructions for future reference

v001: 11/02/20



Power details:

3x AAA battery (not included) or USB

Dimensions: 12.5 x12.5x4.6cm

Fall asleep naturally with this sound therapy machine Features fold away stand to use on bedside


- Auto off timer set to either 15 30 or 45mins
- Can be used with headphones (not wireless)
  - Sound choice of:
    - White noise
      - Ocean
    - Thunder storm
    - Rainforest
    - Rain falling
    - Soft music

#### **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

•

#### Buttons or timer indicator specification:



K1: select to play "White Noise"
K2: select to play "Ocean sound"
K3: select to play "Thunderstorm"
K4: select to play "Rainforest animals sound"
K5: select to play "Rain falling"
K6: select to play "Soft Music"

Timer play button: Set to choose timer for 15min, 30min, 45min, infinite loop, cycle switch Vol Down: The volume goes down Vol Up: The volume goes up Power: Power on/off USB DC 5V: Power in

D1: Indicates timer set to 15min D2: Indicates timer set to 30min D3: Indicates timer set to 45 min

## **Function Operation:**

1. Press and hold down the "Power" button to turn the device on or off. When the power is turned on, sound/music can be selected by pressing "K1" to "K6".

When music plays, press the "Vol down" button to reduce the volume, and press the "Vol up" button to increase the volume. Press the "Timer button" to set the timing shutdown, or to turn off timing. When you set the timer shutdown, the clock starts immediately and automatically shuts down when it reaches the set time. When the device can be powered by USB, using "USB DC 5V" port.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk




\*Calls cost 7 pence per minute plus your telephone company's network access charge Please read and retain these instructions for future reference

2. Timer selection:

Timing time selection (15min, 30min, 60min, infinite loop) Timer 15min: indicator D1 light on; sound is stopped and light turns off after 15min. Timer 30min: indicator D2 light on; sound is stopped and light turns off after 30min. Timer 45min: indicator D3 light on; sound is stopped and light turns off after 45min. Infinite Loop: all indicator lights are off

3. Each time the timer play button is pressed, a timing can be chosen and the corresponding indicator light comes on. The circling sequence is as below:



When selection is made, the indicator light turns on and the time function is started.

- 4. The default setting when the power is on is "infinite loop".
- 5. Music button (K1 K6 buttons):

Each button controls to play unique music. Press once to play the current sound repeatedly until it is deselected.

Pressing another music choice button will change the selection. The current music cannot be stopped by pressing the same button again.

### **CARE AND CLEANING INSTRUCTIONS:**

- Always switch off and remove batteries when not in use. •
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth. •

## BATTERIES

- Keep batteries away from children and pets. •
- Do not mix used and new batteries. •
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods. •
- Never dispose of batteries in a fire. •
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance • with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions. •

#### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, in accordance with your local recycling regulations.
- Plastics this is made from the following recyclable plastic.

Plastic Code & Symbol	ABS	CE 🖾 🐼
Notes	Not often or widely recycled	•

At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

> Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk

