

LED Wax Candle Set of 3 Owl Design



Thank you for purchasing our decorative LED Wax Candle Set of 3 Owl Design. We hope you will be happy with your purchase.

Instructions for use:

- 1. Battery compartment is located on the base of the product
- 2. Slide switch on the base to the 'ON' position to turn the product on
- 3. Slide switch on the base to the 'OFF' position to turn the product off.

TO REPLACE BATTERIES:

- 1. Remove exhausted batteries and discard them properly.
- 2. Clean the battery contacts and also those of the device prior to battery installation.
- 3. Install 2 x AA batteries per Candle (NOT INCLUDED) as shown on the battery diagram in battery compartment.
- 4. "+"side of battery should face towards you when installing battery.
- 5. Place battery compartment lid to its original position.

CARE:

- 1. Keep away from water or damp locations.
- 2. For indoor use only.
- 3. Turn off when not use to save battery life.
- 4. Remove used batteries promptly.

This is not a toy. Keep out of reach of children

Battery Warning:

Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (including hydride) Do not mix old and new batteries Exhausted batteries are to be removed The supply terminals are not to be short-circuited Only batteries of the same or equivalent type as recommended are to be used Batteries are to be inserted with the correct polarity

Battery Disposal:

The wheelie bin symbol indicates the product and batteries must not be disposed of in the domestic waste as they can contain substances that are damaging to the environment. Please use designated collection points or recycling facilities when disposing of the item or batteries. Batteries should be removed from the product.

Contact your local waste disposal agency or your retailer for further information

FRC€ Z C

I