



Electric Ceramic Aroma Lamp

Maximum Power: **40W Max**

Power Supply: 230 Volts

Nominal Frequency: 50Hz

Lampholder: **E14**

Technical Data: 220-240V-50/60HZ-40W

**READ ALL INSTRUCTIONS BEFORE USE AND RETAIN THEM FOR FUTURE REFERENCE
FAILURE TO FOLLOW THE INSTRUCTIONS CAN RESULT IN A FIRE HAZARD**

- Remove all packaging before use
- Avoid any damage on the insulation wire. If the lamp does not light up, please verify that the bulb is correctly inserted
- Do not put fingers or hands inside the unit
- Do not immerse under water
- Keep foreign objects out of the wax / oil dish at all times
- The Aroma Lamp becomes very hot during use, do not touch or move whilst working or whilst wax/ oil melts
- The Aroma Lamp uses electricity and is fitted with a 25W Halogen Capsule Bulb.
- Risk of electric shock exists if metal or any other foreign object is inserted into any part of the product
- Only use appropriate properly functioning 230V electrical outlet
- Never leave the product unattended when in use
- Do not use this lamp outdoors, in contact with water neither in humid places

INTERIOR USE ONLY

KEEP OUT OF REACH OF CHILDREN AND PETS

HOW TO USE YOUR AROMA LAMP

- Put 2-3 tablespoon of water in the top dish, then add 3-5 drops of essential oil (not included)
- depending on desired strength
- **DO NOT ADD WATER WHEN USING WAX MELTS**
- Place Aroma Lamp on a levelled, flat, cool, heat-resistant surface away from draughts, other heat sources and flammable objects
- If used on a non-heat resistant surface, damage may occur if the Aroma Lamp is used without
- protective plate or tray
- Plug the cable into an appropriate, properly functioning 230V electric outlet and turn ON the switch
- Allow the heat to melt the wax and fragrance will release into the room
- The top dish will become hot whilst in use, **DO NOT TOUCH** while in use as heated wax can cause burns
- Allow the top dish to completely cool down before touching or moving
- If wax remains in the top dish after use and you wish to remove the wax, wait until the wax hardens and then gently place pressure on one end of the wax to pop the wax out
- Let the Aroma Lamp completely cool before re-use. **NEVER** add water to the top dish while lamp is In use or hot

**DO NOT USE METAL OBJECTS TO CLEAN OUT THE WAX
DO NOT APPLY EXCESSIVE PRESSURE WHEN CLEANING OR REMOVING WAX. THIS MAY CRACK OR
DAMAGE THE TOP DISH**

**CAUTION: AROMA LAMP BECOMES HOT DURING USE. ONLY USE ON A HEAT RESISTANT SURFACE.
IF UNSURE USE A PROTECTIVE PLATE OR TRAY**

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



Batch No: 4568493

Product Code: M202193

Made in China for S&S Enterprises Ltd. 26 Perivale Park Middlesex UB6 7RL

