



Dimensions

23cm x10cm x9.5cm

Warning

- Do not leave unattended or allow to boil dry to avoid damage.
- Remove all packaging and wash before use.
- Check handle security before each use.
- Always match the size of hob to the base of the milk warmer pan so that only the base is heated.
- Do not leave unattended when cooking.
- Do not allow to boil dry to avoid tipping or damage.
- Always use oven gloves when moving hot pans from the hob.
- Do not use if handle is loose or pan is damaged.


CARE AND CLEANING INSTRUCTIONS:

- Allow to cool before cleaning.
- Do not use metal scourers or utensils to avoid scratching.
- Use soft cloth to clean the inner wall of the milk pan.
- Periodically check screw on handle and re-tighten if necessary.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – the handle is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.