



## Dimensions

13cm

## Composition

Glass and LED

- Fun festive lamp creates colourful illumination
- 13cm globe shape
- 3D glass illumination
- Vibrant firework effect
- Colourful
- Mesmerising
- Battery operated (3x AA – not included)
- 6 hour timer

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### Before use

- Remove the battery compartment cover. Insert 3x AA batteries (not included), observing correct polarity as indicated in the battery compartment. Replace the battery compartment cover.

### Using the lamp

- Lamp has three settings on a sliding switch ON, TIMER, OFF
- To turn the Lamp on, slide the switch to position marked ON. The lamp will remain on until switched off
- To use the Timer function, slide the switch to the position marked Timer. The lamp will remain on for 6 hours and then turn off for 18 hours. This will continue as a loop of 6 hours on, 18 hours off until the setting is changed.

### CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

**COOPERS**  
**OF STORTFORD**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.

**BATTERIES**

- Do not attempt to recharge non-rechargeable batteries.
- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

**DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – contains the following recyclable plastic.



Code & Symbol	5 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

UK  
CA

CE

**COOPERS**  
OF STORTFORD

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.