

# Pack of 5 Cob Torches

**G790** v01: 27/05/20

Please read and retain these instructions for future reference

# BERGSTRÖM

## Dimensions

8.5x2.6cm

Each set contains 1x silver, 1x black, 1x red, 1x blue, 1x green

## Composition

Aluminium

- PACK OF 5 EACH IN A DIFFERENT COLOUR
- SAFETY STRAPS
- SUPER BRIGHT COB LED'S
- SMALL BUT PACK A PUNCH!
- MADE OF TOUGH AND DURABLE ALUMINIUM
- PACK OF 5 MEANS YOU CAN HAVE 1 IN ANY PLACE YOU MIGHT NEED, CAR GLOVEBOX, HANDBAG, SHED ETC
- EACH TORCH USES 3XAAA BATTERIES NOT INCLUDED



## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### BEFORE USE/REPLACING BATTERIES:

- Unscrew the torch base, remove battery holder and fit 3x AAA batteries into each torch base, ensuring the correct polarity is observed.
- Re-fit the battery holder into the stem and screw on the torch base. Ensure the torch base is tightened fully.

### OPERATION:

- To turn the torch on, press the black button at the base of the torch until it clicks.
- To flash the torch, once it is turned on slightly press the black button and release.
- To turn off, press the black button in until it clicks again.
- Once performance reduces, the batteries will need to be replaced.

### WARNING:

- Never point the torch directly towards your eyes or the eyes of others.

### CLEANING:

- Wipe clean with a soft cloth.
- Do NOT use abrasives.

### BATTERIES


- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.

- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	PC, ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

