



Shaver Sharpener



1. Open sharpener by separating the two pieces.
2. Lift off the top part of shaver and remove only one blade at a time.
3. Place the cutting edges of blade on the abrasive surface of smaller part of sharpener.
4. Place second piece of sharpener on top so that it covers both the blade and the other piece.
5. Holding the pieces together and then place the small opening over the shaft of your shaver.
6. Turn shaver on for 10 seconds.
7. Remove the sharpened blade and return it to shaver.
8. To sharpen other blades follow steps 3-7. Blades can be sharpened every 6-8 weeks.
9. For rotary shavers only.
10. Clean with cold water after each use.



Product Code: P151522

Made in China for S&S Enterprises Ltd. 26 Perivale Park Middlesex UB6 7RL