Please read and retain these instructions for future reference

v001: 03/08/20



Dimensions

30cm x16cm

- ANIMATED, SINGING & DANCING SANTA CLAUS DECORATION
- SINGS Holly Jolly Christmas song
- FLASHING LED PRESENT PARCEL
- Santa bops from side to side
- 3x AA batteries required (not included)

Adult Gift. This is not a toy. Keep away from children. Warning! Contains small parts - choking hazard.


ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

- Before first use, remove the plastic battery saving tab.
- Install 3x AA batteries (not included) and turn the switch to ON.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.








Please read and retain these instructions for future reference

v001: 03/08/20

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.





Code & Symbol	HDPE	PVC PVC	LDPE
Type of Plastic	High-Density Polyethylene	Polyvinyl Chloride	Low Density Polyethylene
Commonly used for	Milk bottles, cleaning product bottles, yoghurt pots, butter tubs and other food containers	Pipes, construction material, flooring, windows, guttering, plister packs	Shopping bags, bread bags, squeezy bottles, stretch/pallet wrap, bubble wrap, multi-pack can holders
Notes	Commonly recycled and collected from household recycling bins. Check with your local authority	Not usually colellected from household recycling bins, Sometimes recycled at local waste management centres.	Usually recyclable supermarket deposit points. Check other plastic films as any nonpolythene film e.g. cling film, crisp packets film lids

At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



