

**Dimensions**

15cm diameter, 17.5cm height

Diameter of glass ball 10cm

Composition

Resin and glass

Requires 3x AAA batteries (not included)

- Musical snow globe
- Glass ball with slow LED colour change lights inside and snow effect
- Dickensian style scene in globe
- Carol singing around the tree
- Tree and train base

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

To operate change 3 way switch on the bottom of the poly resin base from OFF to ON or ON-with music.

Eight cycle songs:

1. Jingle Bells	5. Joy to the World
2. We wish you a Merry Christmas	6. The First Noel
3. Silent Night	7. Hark! The Herald Angel Sing
4. Deck the Halls	8. Oh, Christmas Tree

Songs are played in a loop depending on when the item is switched on/off and what songs are playing at that point.

CARE AND CLEANING INSTRUCTIONS:

- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

