Tape Measure with LCD Pad

G953 v01:

Please read and retain these instructions for future reference



- GREAT TAPE MEASURE WITH A NEW TWIST
- NEVER BE WITHOUT A PEN OR PAD AGAIN AS THIS TAPE MEASURE HAS AN LCD WRITING PAD ON THE SIDE OF THE TAPE MEASURE, WHERE YOU CAN JOT DOWN MEASUREMENTS AND NOTES. USING THE INTEGRAL STYLUS
- WHEN YOU ARE DONE WITH THE NOTES SIMPLY PRESS THE BUTTON AND CLEAR THE SCREEN
- BELT CLIP AND HAND LOOP
- LOCKABLE TAPE MEASURE THAT MEASURES UP TO 5M



Dimensions

6.8cm x3cm x7cm Weight: 142g


Tape: L5m xW19mm


Powered by CR1225 in built-battery


ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Parts







Tape Measure with LCD pad

G953

Instructions for Use

Please read and retain these instructions for future reference

v:001 24/07/20


User instructions


- 1. Pull out of the tape claw to measure. You can lock the tape by pushing the manual lock pusher. Push in the opposite direction to take tape back in.
- 2. Write on the LCD screen with the pen provided and erase by pressing the erasing button.
- 3. The tape measure can be pinned on a belt with the pinner.

Tape claw auto correction

0 base point on outside edge of tape claw

0 base point on inside edge of tape claw





BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags Contains the following recyclable plastic.



Code & Symbol	∑5 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins
	(packaging tape itself not recyclable but does not interfere with cardboard)

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

