

Cordless Task Lamps

H019 v03: 13/04/22

Please read and retain these instructions for future reference

BERGSTRÖM



Dimensions

19.5cm x10cm x17cm

Composition

ABS

- WITH 12 ULTRABRIGHT LED LAMPS THIS CORDLESS LIGHT CAN BE TAKEN WITH YOU ANYWHERE
- GREAT FOR EMERGENCY LIGHTING, DIY, READING, WRITING, CARAVANNING ETC
- WITH A PIVOTING HEAD YOU CAN POSITION IT AT THE PERFECT ANGLE NEEDED
- LED LIGHTS LAST UP TO 100,000 HOURS
- PUSH BUTTON ON/ OFF SWITCH

Each lamp is powered by 3x 1.5V DC AA batteries (not supplied)

LEDs not replaceable



ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:


Unpack the components carefully. Please check all parts have been removed from the packaging.

Requires 3x 1.5V 6 AA batteries (not included)

- Open the battery compartment lid
- Insert 3 AA batteries
- Replace the battery compartment lid.

On/Off button modes:

Press once to switch on
Press again to switch off



CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.

The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
Please check with your telephone supplier.

- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer’s safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS
Commonly used for	CD’s, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product’s lifespan please check with your local council authorised household waste recycling centre for disposal.

