

# EZ Skirting Board Cleaner

H038 v02: 03/10/22

Please read and retain these instructions for future reference



## Dimensions

10 x8 x106cm extending up to 127cm

- HAVE YOUR SKIRTING BOARDS LOOKING LIKE NEW AGAIN!
- CLEANING SKIRTING BOARDS CAN BE A REAL PAIN FROM HAVING TO BEND DOWN TO CLEAN OR CRAWLING ALONG ON YOUR KNEES
- BUT WITH OUR EZ SKIRTING BOARD CLEANER YOU NO LONGER HAVE TO BREAK YOUR BACK! SIMPLY WALK ALONG AND GLIDE THE PAD ALONG THE SKIRTING BOARDS
- YOU CAN USE DRY FOR A QUICK DUST OR WET TO REALLY GET THEM GLEAMING
- THE HANDLE EXTENDS UP TO 127CM SO YOU CAN REACH HIGH AS WELL AS LOW
- THE CLEVERLY DESIGNED MICROFIBRE HEAD IS SHAPED PERFECTLY TO GET INTO EVERY GROOVE OF YOUR SKIRTING BOARD
- SWIVELLING HEAD FOR CLEANING AT ANY ANGLE
- COMES WITH 3 REPLACEABLE MICROFIBRE HEADS

## Parts



1. Start by connecting the lower handle to one of the middle handles. Make sure that the holes of the lower handle are aligned with the buttons on the middle handle.
2. Connect the second middle handle to the end of the assembly. Make sure that the holes of the first middle handle are aligned with the buttons of the second middle handle.
3. Next, connect the top handle to the end of the middle handle. Make sure that the holes of the middle handle are aligned with the buttons of the top handle.
4. Attach the head of the cleaner by screwing it onto the lower handle.
5. If you need to clean the cleaning pad, simply peel it from the head unit. Replace the cleaning pad by attaching the back of it to the head.

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269


\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.



### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.