Aerator Sandals

H070 v01: 21/08/20

Please read and retain these instructions for future reference





Dimensions

Soles: 30x13cm (One Size Fits All)

Spikes: 4.8cm Long

- HELP KEEP YOUR LAWN HEALTHIER
- THESE AERATING SANDALS WILL ALLOW OXYGEN TO REACH THE GRASS ROOTS WHILST ALLOWING WATER TO SOAK INTO THE SOIL MORE EFFICENTLY, LOOSENING SOIL AND HELPING FERTILIZERS GET TO THE ROOTS
- THESE SANDALS HAVE 4 STURDY STRAPS THAT YOU CAN ADJUST TO YOUR FOOT SIZE. THE SOLES ARE MADE FROM REINFORCED PLASTIC WITH 13 4.8CM SPIKES THAT DO NOT RUST AND STAY SHARP
- JUST WALK ALONG YOUR LAWN WITH THEM ON AND JOB DONE
- RINSE WITH WATER TO CLEAN

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Warning

- Spikes are sharp.
- Only use to aerate grassy areas or to spike muddy ground. Do not use for any other purpose.
- Do not wear to walk on paths, patios or other firm ground as this may cause damage to the spikes
 or cause the user to fall.
- Check suitability of ground before use. Dry ground may require watering before use.



Parts


Shoes x2
Short metal straps x2
Middle metal straps x2
Long metal straps x2
Heel straps x2
Screw spikes x26
Nuts x26
Spanner x1

Please read and retain these instructions for future reference

v001: 21/08/20



Step One Insert spikes into holes and tigthen with spanner Turn clockwise.



Step Two Assemble straps as shown in illustration.



Step 3 Tighten straps to adjust

Aerator Sandals

H070


Instructions for Use

Please read and retain these instructions for future reference

v001: 21/08/20

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.





Code & Symbol	<u>\$</u>
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

