Pk2 Omelette Makers

H099 v01: 30/09/20

Please read and retain these instructions for future reference



Dimensions

Folded – 22 x13.5 x6.5cm Unfolded – 27 x19 x4cm


- MAKE QUICK NO FUSS OMELETTES THAT ARE FILLING HEALTHY AND DELICIOUS IN NO MORE THAN 3 MINUTES
- THE ROUNDED EDGES EVENLY COOK THE OMELETTE WITHOUT BURNING THE EDGES.
- STEAM YOUR VEGETABLES INSIDE BEFORE ADDING TO YOUR OMELETTE.



Instructions



Place 2 to 3 eggs in the omelette maker and mix with a filling of your choice.
Flip omelette cooker over to fold in half.



Place into the microwave and cook for 40-60 seconds.

Note: Time will vary depending on your microwave power



Unfold to remove cooked omelette with a spatula.

Cleaning & Maintenance

Dishwasher safe

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags Contains the following recyclable plastic.



Omelette Maker

H099

Instructions for Use

Please read and retain these instructions for future reference

v001: 30/09/20

| Code & Symbol | OTHER |
|-------------------|--|
| Type of Plastic | Silicone |
| Commonly used for | CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses |
| Notes | Not often or widely recycled |

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

