H105

## Instructions for Use

Please read and retain these instructions for future reference

v001: 12/10/20



#### **Dimensions**

Tray: W34 xD24 xH2.5 Mesh: W30 xD20cm

- REDUCED FAT BACON COOKING
- NON STICK COATED
- HEALTHIER AND QUICKER WAY TO COOK BACON WITH LESS MESS!
- DRIP PAN CAN DOUBLE INTO A BAKING SHEET!

#### **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

WARNING: Failure to follow these instructions may result in personal injury or property damage. Do NOT use on stovetop, in a microwave or over a direct flame.

**Usage:** Before first use, wash pan in warm, soapy water, rinse and dry completely. Always use potholders when handling hot bakeware. This product is safe for use with metal spatulas. Do not use utensils with sharp or serrated edges, and avoid pressing down hard on the pan when using metal spatulas. Do not use for long term storage of food.

Maximum oven safe temperature: 220-240°C.

#### **Features**

- Elevated mesh basket allows air and heat to circulate around the food for 360° cooking without flipping or burning. Use less or no oil or cooking spray for cooking.
- Non-stick coating for effortless food removal and easy cleaning.
- Frying basket includes easy-carry handles. Always use oven gloves or potholders.

#### **CARE AND CLEANING INSTRUCTIONS:**

- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Clean-up: hand wash in warm, soapy water, rinse and towel dry. Do not clean with metal pads, steel wool, scouring pads or abrasive cleaners.
- Dishwasher safe

#### **DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags this is made from the following recyclable plastic





### H105

# Instructions for Use

Please read and retain these instructions for future reference

v001: 12/10/20

Code & Symbol	OTHER
Type of Plastic	Please Specify (includes ABS, Nylon)
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.