

# Long Reach Footcare Pro

J073 v01: 25/05/22

Please read and retain these instructions for future reference

# vivadia

## Dimensions

27.5 x15.5 x5.5cm



- EASILY REACH YOUR TOES AND FEET
- SAVE MONEY ON SALON PEDICURES BY DOING SO AT HOME
- BATTERY OPERATED 2x AA REQUIRED
- 10 HEADS / FILES INCLUDED
- EASILY TRIM, SHAPE, BUFF AND POLISH. FOOT CANE ALSO REMOVES CALLUSES
- REACHES TOENAILS AND HEELS NO NEED TO BEND OVER. MAKES YOUR FEET NICE AND SMOOTH

## Before using the Footcare Pro

The Footcare Pro is powered by 2x AA batteries (not included). For the best results, use alkaline batteries. To insert new batteries, simply unscrew the blue battery door on the rear of the unit as shown in Figure #1.




Figure #1

Now insert the batteries as shown in Figure #2. To close the unit, screw the battery door back on securely.




Figure #2

## Attaching and Removing the Attachment Heads

To attach a Footcare Pro attachment head, gently press the shaft of the head into the hole on the nose of the Footcare Pro until it feels secure. (Figure #3). Do not force the head or use any tools, this may cause damage to both the head and the Footcare Pro. To remove the head, gently slide the shaft out of the unit. Again, do not use any tools and take care not to accidentally press the ON button while attaching or removing a head.




Figure #3

## Turning the unit ON and OFF

Simply press the button on the Footcare Pro handle and it will stay on as long as it is pressed. To shut off the unit, simply let go of the button and the Footcare Pro will stop. Always check to make sure that the attached head is secure, and never start the Footcare Pro if an attached head feels loose or looks worn.

# The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.

## Using the Footcare Pro

1. For best results, soak hands and feet in gentle, warm soapy water to soften the nails and hardened areas. Dry hands or feet before use.
2. You can use the various attachments to shape nails and smooth skin.
3. Using as little pressure as possible, apply the head to the nail in a continuous gentle motion. **DO NOT KEEP THE HEAD STEADY ON ONE AREA**, this may cause burning or damage to the nail.
4. Use Footcare Pro in small increments, stopping frequently to check, **DO NOT** attempt to shave off too much at a time.

## Attachment Heads

### Professional Foot Cone

Reduces thick toenails and small calluses.



### Ball Tip Cone

Great for hard to reach edges.



### Diamond Cone

Trims toenails to perfection.



### Bullet Cone

Instantly removes stubborn, and dry cuticles.



### Satin Bristle Brush

Removes nail dust and assists in applying oils and creams.



### Flat Disc Trimmer

Designed for fine trimming.



### Rotary Emery Board

Staple for every nail care pedicure.



### Felt Cone Head

Smooths and shines nail surfaces.



### Emery Barrel

Helps gently remove dry skin.



### Shaping Cone

Especially designed for hard to reach corners.



### Cleaning and Storage

Remove any head still in the Footcare Pro and wipe the unit clean using a dry cloth. Do not submerge or expose to water. Store in a dry protected area away from children. Take care that the button will not become depressed during storage, wasting the battery.

### Warning

- For intended use only.
- For external use only.
- Do not affix or force the button to stay on continuously, this is a safety hazard.
- Keep away from long hair, there is a tangling hazard.
- Do not use near water.
- Stop use immediately if you experience pain or discomfort.
- Do not use on irritated skin.


### BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer’s safety, usage, and disposal instructions.

### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product’s lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 PS
Type of Plastic	Polystyrene
Commonly used for	Insulation boxes, water cups, protective packaging inserts, take away containers
Notes	Not commonly recycled but waste management centres will recycle it.

