

Digital Bathroom Scales

H127 v01: 09/09/20

Please read and retain these instructions for future reference

vivadia



Dimensions

28 x28cm

- CAPACITY:5.0-180KG/396LB
- GRADUATION:100G/0.2LB
- EQUIPPED WITH HIGH PRECISION STRAIN GAUGE SENSOR SYSTEM
- TEMPERED SAFETY PLATE GLASS PLATFORM
- OVERLOAD INDICATOR Max weight 180kg
- LARGE PLATFORM – STYLISH VIBRANT PATTERN
- EASY TO READ LCD DISPLAY WITH BLUE BACKLIGHT
- CHOOSE BETWEEN KG/LB/ST – HIGH PRECISION SENSORS
- TEMPERED GLASS SAFETY PLATE GLASS PLATFORM
- FOOT-TAP SWITCH
- AUTOMATIC ZERO RESETTING
- AUTOMATIC SWITCH OFF / LOW BATTERY INDICATOR
- OPERATED BY 2XAAA BATTERY (INCLUDED)

The scales are designed for household use only, not to be used for commercial purposes

Installing batteries

1. Remove the battery cover at the back of the scales.
2. Insert 2x1.5V AAA batteries (included) into the scale correctly.
3. Put on the back battery cover.

Operating Instructions

1. Select the between (Kg/Lb/St) using the switch located on the back of the scales.
2. Place the scales on a firm, flat and even surface to ensure accuracy.
3. Standing on the platform directly the scales weigh you automatically.
4. After the weight is displayed, the scales will automatically switch off after 6 seconds.

Overload indicator

When the LCD screen display "ERR" it indicates that the maximum weight (180kg) has been exceeded.

Low Battery Indicator

When the LCD screen display "LO" you should install new batteries.

Advice for use and care

1. Ensure the scales are on a flat, even and firm surface. Avoid carpet or soft surface.
2. The surface of the scales will be slippery if wet, keep the scales dry.

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

3. Clean after use with a lightly damp cloth. Do not use solvents or immerse the product in water.
4. Avoid overloading the scales, otherwise, permanent damage may occur.
5. Do not store the scales in an upright position when not in use as this will drain the battery
6. Avoid excessive impact or vibration to the unit, such as dropping the scales onto the floor or object onto the scales.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

