

Magnifying Nail Clippers

H139 v01: 12/08/20

Please read and retain these instructions for future reference

vivadia



Dimensions

10cm x6.2cm x5cm

CR2016 x2 required (supplied)

Lens size: approx. 35mm diameter
Magnification: approx. 3.5x
Light: white LED x3 (LEDs not replaceable)
Power: Button battery CR2016 (DC3V) x2
Working time: approx. 5 hours
Size: 105 x53 x60mm
Weight: approx. 93g (with batteries)
Materials: Lens: super white glass
Body: ABS
Nail Clipper: stainless steel

Accessories

Batteries for testing (CR2016 x2), lens cloth, manual


- NAIL CLIPPERS WITH 3.5X MAGNIFIER
- USE WITH OR WITHOUT THE MAGNIFIER, THIS IS A SIMPLE MAGNETIC TOP THAT CLIPS ON
- NAIL FILE CIRCLE TO UNDERNEATH SO YOU CAN FILE AND CUT
- LED LIGHT BUTTON ON TOP OF UNIT
- METAL CLIPPER HANDLE
- COMFORT TOE/FINGER PAD AT FRONT FOR EXTRA COMFORT
- NON SLIP RING ON BOTTOM

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:


Unpack the components carefully. Please check all parts have been removed from the packaging.

Preparations

1. Turn the bottom lid to the left (1). Remove the lid (2).



2. Remove the insulation film. Put the lid back and turn to the right to close.



Changing the batteries

Remove the current batteries for a new set of CR2016 x2 and stack together with the + side up.

Beware

The batteries provided are for test purposes only and are not long lasting. Please have replacement batteries to hand on stand-by.

Cautions



Improper use may result in serious health issues.

- Do not leave under or focus sunlight or other light sources through the lens. Focused sunlight or strong lights may cause eye damage.
- Keep out of the reach of children.
- Children may swallow parts or injure themselves. Do not point LED light directly to your eyes. It may hurt your eyes.
- Do not expose to fire or apply heavy pressure. May cause malfunction and a compromised battery is extremely risky.



Improper use may result in damages or injuries

- Do not operate or touch metal/batteries with wet hands.
- There are risks of suffering electrical shock.
- Do not disassemble or remodel the product. Doing so may result in injuries.
- Keep in a dry environment whilst not in use.

Operation

Soften the nails before cutting.

Using the LED

Press the button over the lens to turn the LED on/off.



Use clippers to cut your nails.

Nail file

Use nail file on the bottom of the lid to polish nails

Cleaning

The upper lens part can be easily removed/attached with its magnetic anchors. Remove the upper part to help clean the lens and any nail residue in the casing.




BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

