# Ornate Mosquito Killing Lamp н288

Instructions for Use

Please read and retain these instructions for future reference

v002:14/06/21




## Dimensions 13 x13 x3.5cm

- THIS ORNATE ARABESQUE INSECT KILLING LAMP ATTRACTS BUGS WITH ITS BUILT IN LIGHT AND THEY DESTROYS THEM ON CONTACT WITH THE ELECTRIC GRID
- INDOOR USE ONLY
- MAINS POWERED
- 220-230V a.c., 50/60Hz, Class II, 3W

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.





Please do not touch the electrified wire netting with hands or other metal sundries to avoid dangerous accidents while using.

## SAFETY INSTRUCTIONS:

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- THE PRODUCT IS FOR INDOOR USE ONLY. IT IS NOT SUITABLE FOR USE OUTDOORS
- WHILST IN USE, DO NOT TOUCH THE METAL NET
- THIS IS NOT A TOY
- KEEP OUT OF REACH OF CHILDREN
- DO NOT USE THIS PRODUCT IN AREAS WHERE THERE MAY BE FLAMMABLE GAS OR EXPLOSIVES
- IF THE WIRE MESH IS BROKEN, DO NOT PULL AT IT

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk



\*Calls cost 7 pence per minute plus your telephone company's network access charge

# Ornate Mosquito Killing Lamp н288

Instructions for Use

Please read and retain these instructions for future reference

- THIS APPLIANCE IS NOT INTENDED FOR USE BY PERSONS (INCLUDING CHILDREN) WITH REDUCED PHYSICAL, SENSORY, OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE, UNLESS THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING THE USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY. CHILDREN SHOULD BE SUPERVISED TO ENSURE THEY DO NOT PLAY WITH THE APPLIANCE
- TO PROTECT AGAINST ELECTRIC SHOCK, DO NOT IMMERSE CORD, PLUG OR APPLIANCE, IN WATER OR ANY OTHER LIQUID.
- UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING.
- DO NOT OPERATE ANY APPLIANCE WITH A DAMAGED CORD OR PLUG OR AFTER THE APPLIANCE MALFUNCTIONS, OR HAS BEEN DAMAGED IN ANY MANNER. WE RECOMMEND THAT THE POWER CORD IS NOT KINKED OR STORED IN A TWISTED MANNER, AND THAT YOU REGULARLY CHECK ITS CONDITION.
- THE USE OF ANY ACCESSORY ATTACHMENTS NOT RECOMMENDED BY COOPERS OF STORTFORD MAY CAUSE INJURIES AND INVALIDATE ANY WARRANTY YOU MAY HAVE.
- DO NOT LET CORD HANG OVER THE EDGE OF A TABLE OR COUNTER, OR TOUCH HOT SURFACES.
- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- USE ON A LEVEL, STABLE SURFACE.
- **DO NOT** COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- ENSURE THERE IS SUFFICIENT DISTANCE BETWEEN THIS APPLAINCE AND OTHER ITEMS ON THE WORK SURFACE OR WORK STATION, OR SUFFICIENT DISTANCE BETWEEN THE APPLIANCE AND THE CONFINES OF THE AREA IN WHICH IT IS SITUATED. WE RECOMMEND A MINIMUM CLEARANCE AROUND ALL FACES OF AT LEAST 10CM.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.

## **Function and Features**

This product is environmentally friendly. It does not use any insecticide. It is odourless and is harmless to humans, flora and fauna. It produces no pollutants.

The product lures mosquitoes and other pests efficiently, using static electricity to eliminate pests that fly into the wire mesh.

Its circuitry is designed to produce a strong effect, using low power

## Usage & Scope

## Suitable for use in any indoor space

- For best results, avoid using in areas where there are other strong light sources. If using in the bedroom turn on the Mosquito Killing Lamp, but not the main light before retiring, then turn off after 10-20 minutes. The ideal height for use is around 1 meter off the floor. For best results, use the product on the windowsill.
- To prolong the life of the product, do not keep the Mosquito Killing Lamp in constant use

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk



Instructions for Use

Please read and retain these instructions for future reference

### Common causes of stoppage

- Should the tube start flickering, the voltage may be too low or the item has been in use for a long period of time. Turn off unit and allow it to rest
- Do not attempt to repair the product

### Maintenance


- Dead insects may need to be removed from the mesh periodically. Make sure to turn off the unit
- Do not clean with water. Wipe with a dry cloth.
- Avoid jarring the unit

### PLUG WIRING (UK & IRELAND)

This appliance is fitted with a BS 1363 13-amp plug. If you have to replace the fuse, only those that are ASTA or BSI approved to BS1362 and with a rated current of 13-amps should be used. If there is a fuse cover fitted, this cover must be re-fitted after changing the fuse. If the fuse cover is lost or damaged the plug must not be used. Spare fuse holders and fuses are available from electrical outlets. If the socket outlets in your home or office are not suitable for this product's plug, the plug must be removed and disposed of safely. Attempts to insert the plug into the wrong socket is likely to cause electric hazard. A replacement plug should be wired according to the following instructions:

#### The cable

A mains electricity cable contains two or three inner wires. Each has a core of copper and an outer layer of flexible plastic. This product is double insulated; the wires in the cord set are colour coded in the following way:



BLUENEUTRALBROWNLIVEGREEN & YELLOWEARTH

The diagram shows the key features of a correctly wired three-pin mains plug.

Note:

Double insulated appliances do not need the green & yellow Earth wire. They may only have the Brown and Blue wires.

### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



FORD

• Plastics, polybags – Contains the following recyclable plastic.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk

\*Calls cost 7 pence per minute plus your telephone company's network access charge

Instructions for Use

Please read and retain these instructions for future reference

Code & Symbol	OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk



\*Calls cost 7 pence per minute plus your telephone company's network access charge