

Rainbow Spinner Stake

H312 v001: 16/12/20

Please read and retain these instructions for future reference

GAINSBOROUGH

Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

Windmill Diameter : 36cm, TOTAL SIZE

36 x6 x152.5CM

- WONDERFULLY COLOURFUL RAINBOW SPINNER WILL GIVE YOU A REAL BURST OF SUMMER JOY
- CRACKLED BALL IN THE CENTRE OF THE SPINNER COLOUR CHANGES FOR A SPECTACULAR LIGHT SHOW AT NIGHT
- THE DOUBLE SIDED SPINNER IS COVERED IN MULTI-COLOURED OVALS AROUND A METAL FLOWER SHAPE
- SPINNING IN THE WIND IT WILL ADD A MOVING COLOURFUL FEATURE TO YOUR GARDEN
- SOLAR POWERED

Battery: 1.2V AA 400mAh NI-MH rechargeable battery

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.


Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Assembly



BEFORE FIRST USE: Remove the protective film from the solar panel.

CHARGING AND OPERATION:

1. Set switch (located on the bottom of the solar crackle ball) to "ON" position, Charge the solar product by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

IMPORTANT:

1. Install the solar product in an area where it can get direct sunlight.
2. Leave the switch to "ON" position.
3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.

Battery replacement:

Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included) .

Step2: Remove the exhausted battery and install 1x new AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. During the winter if you can bring it inside and give a good clean ready for next year.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



GAINSBOROUGH
Garden & Wildlife

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk