

30cm Light Up Autumn Hanging Basket

H594 v001: 15/02/21

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife



Dimensions

(H) 30.5 x(W) 25.5 x(D) 25.5cm

Batteries: 2x AA 1.5V (not included)

10 x Warm White LED Lights (not replaceable)

Battery box size: 7.5*3.5cm(L*W)

- SEASONAL ARTIFICIAL AUTUMN HANGING BASKET IS AN ARRAY OF RICHLY COLOURED FLOWERS AND AUTUMN FOLIAGE
- WITH WARM WHITE LEDS (not replaceable) SCATTERED ALL OVER IT, POWERED BY 2XAA BATTERIES (NOT INCLUDED) ITS EVEN STRIKING AT NIGHT
- A MIX OF SUNFLOWERS, PINE CONES, BERRIES & AUTUMN LEAVES IT FEELS LIKE IT HAS COME STRAIGHT OUT OF A BEAUTIFUL AUTUMN FOREST
- AND AS ITS ARTIFICIAL THERE IS NO MAINTENANCE

For indoor and outdoor use. For outdoor use hand in a sheltered position.

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

OPERATION:

The battery box sits inside the basket on the end of the lights.


1. Set button to "ON" position.
2. The light will work.

NOTE: In order to verify that the button is correctly in the "ON" position, set button to ON position. If the light is working the button is in the correct position.

IMPORTANT:

1. Install 2 x AA 1-5VDC new batteries. Do not use used or old batteries
2. Leave the button in "ON" position to allow light to light up.

ON/OFF button



MAINTENANCE AND TROUBLESHOOTING:

1. Make sure the switch is set to "ON" position.
2. If product does not light up, replace the replaceable batteries as they may be weak or worn out. (Battery 2pc "AA" 1.5v- Same equivalent type as recommended must be used).

*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

30cm Light Up Autumn Hanging Basket H594 Instructions for Use

Please read and retain these instructions for future reference

v001: 15/01/21

BATTERY REPLACEMENT:

Step1: The battery compartment is in the box. Remove battery box sliding cover by sliding the cover down.

Step2: Remove the exhausted battery and install 2pcs new AA battery according to the polarity symbol indicated on the battery compartment.

Step3: Replace battery box cover, slide it back into right position.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

