Please read and retain these instructions for future reference

v001: 26/05/21



Dimensions


25.4 diameter x 4.5 cm

- ENJOY 12 SECONDS OF BIRD-CALL SONG FROM 12 FAVOURITE NATIVE BRITISH BIRDS SINGING ON THE HOUR
- 3*AA BATTERIES NOT INCLUDED
- FALLS SILENT BETWEEN 10PM-5AM
- ABLE TO DISABLE BIRD SOUNDS IF PREFERRED WITHOUT AFFECTING THE CLOCK MECHANISM
- MAHOGANY WOOD-EFFECT BEZEL

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Settings



Requires 3 x AA LR6 (1.5V) batteries, 1 for the movement and 2 for the music block. Hourly music is pre-set from 6:00 a.m. to 9:00 p.m. Silent from 10:00 p.m. to 5:00 a.m. Please follow instructions carefully.

- 1. Pre-set the clock time at 5:50 a.m. prior to placing AA batteries into the battery compartment (Position 3 & 4).
- 2. Place 2x AA batteries into the music block, then 1 x AA battery into the movement.
- 3. Adjust the time clockwise to the local time, the correct hourly music will be played while the clock time is setting.

Remove the batteries from part 3 (Music part battery compartment) to disable the bird sound.

Please read and retain these instructions for future reference

v001: 26/05/21

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	<u> </u>	65 ps
Type of Plastic	Polypropylene	Polystyrene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups	Insulation boxes, water cups, protective packaging inserts, take away containers
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)	Not commonly recycled but waste management centres will recycle it.

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



