



**180L WARM WHITE LED**  
**45CM X 45CM BLACK CROSS BASE**  
**5M LEAD CABLE**  
**Composition**

- WIRED POSITIONAL BRANCHES SO THAT YOU CAN POSITION TO YOUR LIKING
- WARM WHITE LEDS GIVE A BEAUTIFUL EFFECT AND ARE ENERGY EFFICIENT
- ADDS ATMOSPHERE IN ANY ROOM
- CAN ALSO BE USED OUTDOORS

SPECIFICATION	
KEEP THIS INFORMATION FOR FUTURE REFERENCE	
Rated Voltage:	24V
Total Product Rating :	6W
Nominal Frequency :	50-60 Hz
Total bulbs per set	180
LED bulbs :	3V 0.02A 0.06W NON REPLACEABLE
Transformer Plug:	31V DC 3.6VA

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### Instructions for use

This product is suitable for indoor and temporary outdoor use (during the festive season, parties, etc), but the transformer must be located indoor and must not be operated in moist or very humid conditions. The light set operates with a 31V isolating transformer. Only use with the 31V transformer supplied.

### Installation

1. Carefully open the packaging and remove the tree top, metal tube, tree stand, transformer, plastic flowers if any have come off the lights.
2. After unpacking the product, place the tree stand on a level surface. Pull apart the legs of the stand so that they are "X" shaped.
3. Carefully insert the metal tube into the assembled stand. Make sure the pole is firmly inserted into the stand and secured with the locking wing bolt. Connect the tree top by slotting into the top slot of the preceding section.
4. If some of the flowers have come off, carefully push them back on the lights.
5. Create the shape of the tree by gently expanding the tree branches
6. Connect the light chain cable to the transformer then plug the transformer into the mains.
7. The transformer must be located indoors only.

## Warnings

- Do not connect the chain to the supply while in packaging.
- The product is for outdoor/indoor use, but the transformer is for indoor use only.
- Individual LED bulbs are not replaceable.
- Do not connect this chain electrically to another chain
- The external flexible cable of the luminaries cannot be replaced. If the cord is damaged, the luminaries will have to be destroyed.
- Never allow any part of the set to come into contact with a source of heat or flame.
- This product is for use as a decoration only. Please do not treat as a toy and keep it out of reach of small children.
- Always turn off the lights overnight or if unattended.
- Do not overload power sockets or extension leads.
- Please unplug the product fully from the mains socket when not in use.
- Do not remove or install the branches while the chain is connected to the power supply.

## CARE AND CLEANING INSTRUCTIONS:

- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

## PLUG WIRING (UK & IRELAND)

This appliance is supplied with a mains adaptor/charger with BS1363 plug pins.


**DO NOT** use if the socket outlets in your home or office are not suitable for this product's mains adaptor/charger plug pins. Attempts to insert the mains adaptor/charger into the wrong socket is likely to cause electric hazard or damage.

**DO NOT** use with any other mains transformer/charger than the one that is supplied with this product.

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics– this is made from the following recyclable plastic.



Code & Symbol	 PVC
Type of Plastic	Polyvinyl Chloride
Commonly used for	Pipes, construction material, flooring, windows, guttering, plaster packs
Notes	Not usually collected from household recycling bins, Sometimes recycled at local waste management centres.

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

