


5pc Robin Light Up Chain

H754 v001: 12/05/21

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife



Dimensions

Each BIRD IS 13.5 x6 x8.5cm

- CUTE ACRYLIC ROBINS JOINED TOGETHER ON A LIGHT CHAIN
- 30CM DISTANCE BETWEEN EACH ROBIN
- 1.2M LONG WITH A 50CM LEAD WIRE (BETWEEN END OF LIGHT CHAIN AND BATTERY BOX)
- IP44 RATED BATTERY BOX SO YOU CAN USE OUTDOORS POWERED BY 3x AA 1.5 V DC (batteries not included)
- TIMER FUNCTION
- EACH ROBIN HAS 8 WHITE LED'S INSIDE (LEDs not replaceable)
- EACH BIRD IS 13.5X6X8.5CM
- SCATTER THEM ALONG BUSHES, PLANTS, HEDGES ETC FOR SOME FESTIVE CHEER

THE PRODUCT IS NOT A TOY!

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.



Battery Box:

Three-position switch functions:

TIMER – the product lights up in repeated cycles daily for 6 hours, then turns off for 18 hours

ON – constantly on

OFF – constantly off

- **ONLY ADULTS MAY CHANGE THE BATTERIES!**
- **MAKE SURE TO INSERT THE BATTERIES WITH THE CORRECT POLARITY!**
- **REPLACE THE BATTERY COMPARTMENT COVER AFTER CHANGING THE BATTERIES!**

WARNING!

- **THE LIGHT SOURCES ARE NOT REPLACEABLE.**

- **DO NOT CONNECT THE CHAIN TO POWER SUPPLY WHILE IT IS STILL IN PACKAGING.**
- **FOR INDOOR AND OUTDOOR USE**
- **DO NOT INTERCONNECT WITH ANOTHER LIGHT FITTING.**
- **DO NOT INTERFERE WITH THE WIRING.**

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Acrylic
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

