5pc Copper Baking Set

H800

Instructions for Use

Please read and retain these instructions for future reference

v001: 29/03/21



- ALL YOUR BAKING ESSENTIALS IN 1 SET
- COPPER PARTICLES IN THE TINS PROMOTE QUICKER COOKING AND AID EVEN BAKING
- BAKE MUFFINS, CAKES AND MORE
- SET INCLUDES: 12 muffin tray: 35 x26.5 x3cm
- cake pan:37.5 x25.8 x5cm
- square cake pan:23.4 x22.3 x5cm
- round cake pan :D24 xH4cm
- cake tin:25.5 x13 x6cm
- NON STICK + EASY CLEAN
- 0.4mm thickness, with copper finish

BEFORE FIRST USE

Before using your new baking tins, please read the following instructions and keep for future reference. Remove all labels.

Before using, wash your baking tins in warm, soapy water then rinse and dry thoroughly. This will remove any residue that is left over from manufacturing and packaging of your new purchase.

- Keep small children away from the baking area while you are baking. Heat, steam, hot food and oils can splatter from baking tin when in use.
- These baking tins are not intended for commercial use.
- Oven safe 210°C.
- Not suitable for Microwave use.
- Not suitable for dishwasher use.
- Never cut food in the baking tins.
- To ensure the longer life of your non-stick baking tins, it is recommended to only use wooden or nylon utensils.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400* Fax: 01279 756 595 www.coopersofstortford.co.uk



*Calls cost 7 pence per minute plus your telephone company's network access charge Please read and retain these instructions for future reference

- With use, slight surface marks, abrasions and discolouration are normal and will not affect the non-stick performance of the surface.
- DO NOT place baking tins on stove top or allow direct contact with flame.

CLEANING FOR NON-STICK

- After baking DO NOT immerse your hot tin in cold water as this may result in irreversible warping.
- Always let the baking tins cool to room temperature before cleaning.
- To prevent scratches, never scrub your baking tins with a steel wool pad or any harsh abrasive cleaners.
- Baking tins are recommended to wash in warm soapy water using a soft sponge or soft brush.

CAUTION:

- Always use an oven mitt or glove when removing from oven.
- Not suitable for dishwasher use.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	ß	Â
	PVC	LDPE
Type of Plastic	Polyvinyl Chloride	Low Density Polyethylene
Commonly used for	Pipes, construction material, flooring, windows, guttering, plister packs	Shopping bags, bread bags, squeezy bottles, stretch/pallet wrap, bubble wrap, multi-pack can holders
Notes	Not usually colellected from household recycling bins, Sometimes recycled at local waste management centres.	Usually recyclable supermarket deposit points. Check other plastic films as any non-polythene film e.g. cling film, crisp packets film lids

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400* Fax: 01279 756 595 www.coopersofstortford.co.uk



*Calls cost 7 pence per minute plus your telephone company's network access charge Instructions for Use