# 25cm Artificial Light Up Bonsai Tree ната Instructions for Use

Please read and retain these instructions for future reference

v00128/04/21



For indoor use only. This is not a toy. Keep away from children.

#### Dimensions (H) 25 x (W) 30 x (D) 15cm Cable length: 100cm

- 10PCS WARM WHITE MICRO LED LIGHTS (not replaceable)
- USES 2X CR2032 BATTERIES, INCLUDED
- 25CM TALL
- PLASTIC POT SIZE 15CM WIDE AT TOP, 8.5CM TALL & 9CM WIDE AT BOTTOM
- BONSAI TREES ARE NOTORIOUSLY DIFFICULT TO CARE FOR AND THANKFULLY OUR ARTIFICAL ONE IS MAINTENANCE FREE WHILST STILL LOOKING REALISTIC
- SCATTERED WITH WARM WHITE MICRO LIGHTS IT LOOKS EVEN PRETTIER AT NIGHT TIME!
- ADD A SYMBOL OF HARMONY AND PEACE TO YOUR HOME

### ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

#### Switch functions:



ON – constantly on OFF – constantly off

#### WARNING!

- The light sources are not replaceable.
- Do not connect the chain to power supply while it is still in packaging.
- FOR INDOOR USE
- Do not interconnect with another Christmas light fitting.
- Do not interfere with the wiring.
- Only an adult person may change the batteries!
- Replace the battery compartment cover after changing the batteries!
- The product is not a toy; do not give it to children!

#### CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk



\*Calls cost 7 pence per minute plus your telephone company's network access charge

## 25cm Artificial Light Up Bonsai Tree н871 Instructions for Use

Please read and retain these instructions for future reference

- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

#### BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

#### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	A B VC	<b>25</b> 3
Type of Plastic	Polyvinyl Chloride	Polypropylene
Commonly used for	Pipes, construction material, flooring, windows, guttering, plister packs	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Not usually colellected from household recycling bins, Sometimes recycled at local waste management centres.	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk

