# Electric Nail Trimmer

H912 v01: 26/05/21

Please read and retain these instructions for future reference





## **Technical data**

Power supply: 2 x AA batteries (not

included – 2 x 1.5V) Voltage: 3V DC

Fast level: 15000rpm/min Slow level: 10000rpm/min

#### **Dimensions**

(L) 13 x (W) 4 x (D) 3cm

- GIVE YOURSELF A QUICK AND CONVENIENT MANICURE / PEDICURE IN THE COMFORT OF YOUR OWN HOME!
- COMPLETE WITH HANDY TRAVEL / STORAGE CASE
- LED LIGHT AT FRONT GIVES YOU A BETTER VIEW (LEDs not replaceable)
- 2 X ADJUSTABLE SPEEDS WITH SINGLE ROTATION DIRECTION WHICH PREVENTS SPLITTING AND BREAKING / DAMAGING NAILS
- 6 X INTERCHANGEABLE HEADS FOR SHAPING, POLISHING, TRIMMING, BUFFING, CUTICLE CARE
- SUITABLE FOR NAILS AND HARD SKIN
- GENTLE ON NAILS AND SKIN, SUITABLE FOR THINNER SKIN


# **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

### Contents

- 1 x Electric Nail Trimmer
- 6 x Filing Tools
- 1 x Storage and Travel Case
- 1 x Instruction manual

## **Parts**



Please read and retain these instructions for future reference


v001: 26/05/21

## Caution

- Keep out of reach of children
- Please remove batteries when not in use
- Do not disassemble and repair the product (no user serviceable parts)
- Do not immerse in water

# **Working modes**

D1 Rotating anti-clockwise at low speed
D2 Rotating anti-clockwise at high speed
G1 Rotating clockwise at low speed
G2 Rotating clockwise at high speed



Description	Image	Function
Filing cone	•	To file and restore a perfect shape to the nail. Gently slide the filing cone around your nails until they have the desired shape and length.
Thin pointed stone		To remove dead skin that surrounds the nail in order to have a clear nail outline.

Please read and retain these instructions for future reference

v001: 26/05/21

Description	Image	Function
Thin rounded stone	_	To file the edge of the nails for more precision, to smooth the nail surface and remove cuticles from around the nail.
Polishing disc	<b>~</b>	To smooth and buff the nails for a glossy finish.
Small fine shaping disc	9	To gently file nails.
Large coarse shaping disc	9	To gently file thicker nails.

### **BATTERIES**

## (2x AA required – not included)

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

## **DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	265 PS	OTHER
Type of Plastic	Polystyrene	Please Specify (includes ABS, Nylon)
Commonly used for	Insulation boxes, water cups, protective packaging inserts, take away containers	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not commonly recycled but waste management centres will recycle it.	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

