Light Up Robin Christmas Canvas

H939 v01: 14/06/21

Please read and retain these instructions for future reference





Dimensions

(H) 40 x (W) 30 x (D) 1.8cm

- REQUIRES 2 X AA BATTERIES (NOT INCLUDED)
- 6 LED LIGHT (not replaceable): AT NIGHT WHEN THE LIGHTS DIM, IT CREATES A LOVELY EXTRA GLOWING DIMENSION WITH ITS OWN TWINKLY 6 LED LIGHTS
- CANVAS MAKE IDEAL EASY CHRISTMAS DECORATION, SIMPLY TAKE AN EXISTING PICTURE DOWN FOR THE DURATION OF THE FESTIVE SEASON AND POP THE CANVAS UP, THEN STORE AWAY ALONG WITH YOUR CHRISTMAS DECORATIONS UNTIL NEXT YEAR
- FEATURES A CHRISTMAS SCENE.
- LED LIGHTS BRIGHTEN UP YOUR WALLS

For domestic indoor use only.
This is not a toy. Keep away from children.

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

INSTALL/REPLACE BATTERIES

- Lift the black cloth under the back of the wall painting. You will see the battery case without cover.
- Remove or replace the batteries.
- Install 2x AA batteries.

CARE AND MAINTENANCE

- Handle with care.
- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.
- Store the item in a cool, dry place and away from children.
- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

Light Up Robin Christmas Canvas нэзэ Instructions for Use

Please read and retain these instructions for future reference

v001: 14/06/21

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	25) P. P. P
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

