

Wall Clock

J017 v02: 08/08/22

Please read and retain these instructions for future reference

BERGSTRÖM



Dimensions

25cm diameter

Requires 1 x AA 1.5V battery (included)

The clock's time setting will occur automatically soon after the battery is inserted. The radio controlled mechanism tunes itself into the correct time after receiving the 'MSF' time signal.

How do I start the clock?


- Remove the plastic tab from the battery compartment on the back of the clock, making sure that the polarities match those shown in the compartment.
- After the battery (AA battery 1.5v, included) is inserted, you will see the second hand move clockwise to the 12 o'clock position. Within four minutes the hour and minute hand will move to the standby position at 12 o'clock.
- The clock will search to receive the radio signal. If the signal in your area is strong, within three to ten minutes the clock will set itself.
- If the signal is weak or the clock is unable to receive the signal the hands will not move. The clock will try to receive the signal once an hour for the first 24 hours. Due to atmospheric conditions, the signal is often strongest between midnight and 4am.
- When the clock has found the signal and finished setting itself it will seek out the signal every second hour on the odd hours (1 o'clock, 3 o'clock etc) to maintain its accuracy.
- If there is no signal for 24 hours the clock hands will stop.
- If there is no signal the clock should be moved to another location in order to receive the signal. The antenna is directional so one location will probably work better than another.

Buttons on the back of your clock

REC

This is to force the clock to receive.

To help with receiving the signal, the REC button can be used. Press for more than 5 seconds. The Second hand, hour and minute hand will move to the 12.00 position. If the clock receives the signal within approximately 8 minutes, it will set the correct time. If the clock fails to receive the signal it will not change.



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

M.SET

If the signal is very weak, pressing the M.SET button for 5 seconds will increase the speed that the clock searches. If it is pressed for only 1 second, the minute hand will move just one place to the next minute position. If no signal is received the clock will operate as a normal non R/C clock.

RESET

To reset the clock and clear the current time, press the RESET button and the hands will move to the 12.00 position ready for receiving the signal again.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PP	 OTHER
Type of Plastic	Polypropylene	Please Specify (includes ABS, Nylon)
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)	Not often or widely recycled



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU
 Tel: 0844 4824400*, Fax: 01279 756595
www.coopersofstortford.co.uk
 EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
 Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
 Please check with your telephone supplier.