K238 v002: 09/11/22

Please read and retain these instructions for future reference





Dimensions

(H) 70 x (W) 58 x (D) 34cm

- **70L ROTARY COMPOSTER**
- HELPS TO COMPOST QUICKER

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE: Unpack the components carefully. Please check all parts have been removed from the packaging.

Parts



A - Main Panel x 2 B- Side panel x7

C-Sliding frame

D - Slide cover x1



E - Main stand x2




G - Metal tube x1






Department





K - Bolt x2







K238

Please read and retain these instructions for future reference

Recommendations for composting

- Empty your recyclable kitchen waste bin every day in order to deter fruit flies and avoid smells.
- Add kitchen towels, paper tissues, toilet roll middles to soak up excess moisture.
- Do not empty liquids into your bin.
- Using brown paper liner or newspaper in your kitchen bin you can simply remove the full paper liner and deposit it in your compost bin.

ASSEMBLE THE MAIN BODY



Attach whisks to the side panels.



Connect side panels using connecting buckles and sliding frame. Arch the 2 sections together to push green clip. Then work your way round.

Fit main panels at top and bottom clipping them in place. Clip together main stand.



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595 <u>www.coopersofstortford.co.uk</u> EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269 *UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

v002:09/11/22

K238

Instructions for Use

Please read and retain these instructions for future reference

v002:09/11/22

ASSEMBLE THE STAND



Connect main stand with side stands.



Push the metal tube through the assembled drum and rest it on the stand.



Fit stand buckle on either side of the stand.





Push metal tube through the drum.



Fit tube plugs to the metal tube on boith ends



Fix metal tubes with bolts and nuts on both ends.

The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595 <u>www.coopersofstortford.co.uk</u> EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269 *UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

K238

Please read and retain these instructions for future reference

v002:09/11/22

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	25 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

The Enterprise Department	UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595 <u>www.coopersofstortford.co.uk</u> EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269 *UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier
Department	