Please read and retain these instructions for future reference



Dimensions

18 X 10.5 X 72.5 CM, 500G

TECHNICAL DETAILS:

- METAL
- ADD DAZZLING MOTION AND SOOTHING **SOUND TO YOUR GARDEN**
- **COLOURFUL WIND SPINNER AND BELL CHIME IN ONE**

Hang the Bee Spinner from a tree branch or porch hook. Allow sufficient clearance for the spinner to rotate freely without obstruction.

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

CLEANING INSTRUCTIONS:

Clean with a dry cloth or duster.

DISPOSAL:

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.