## Solar Light Up Bunting Red, White & Blue K418 v001: 27/09/21

Please read and retain these instructions for future reference

# **GAINSBOROUGH**

Garden & Wildlife ALWAYS POSITION IN DIRECT SUNLIGHT



# Dimensions

12m in length **Material** Polyester

Batteries required: 1 x AA 300mAh rechargeable battery (provided)

- 40 PIECES OF BUNTING, 15CM APART
- WITH 80 LEDS IN RED WHITE & BLUE RUNNING ALONG THE BUNTING POWERED BY A SOLAR PANEL

## **KEEP AWAY FROM POWER LINES AND HEAT SOURCES**

#### **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

#### Before using first time

Remove the protective film from the solar panel. Allow solar panel to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is located on the back of the solar panel. Once the batteries are fully charged, set the ON/OFF switch to ON. If

the lights do not turn on after dark refer to Maintenance section. NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

## Find an ideal Place for the Solar Light.

Place the solar panel in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the panel is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the panel near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the lights from coming on, or cause them to turn off automatically



## MAINTENANCE AND TROUBLESHOOTING:

- 1. Make sure the switch is set to "ON" position.
- 2. Keep the solar panel clean.
- 3. If solar product does not light up after it has been used for around 8 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1x AA 1.2v 300Mah, Ni-MH, Rechargeable– Same equivalent type as recommended must be used).

#### 4. Battery replacement:

Step 1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included).

\*Calls cost 7 pence per minute plus your telephone company's network access charge The Enterprise Department Head Office: 11 Bridge Street Bishop's Stortford, CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk

# Solar Light Up Bunting Red, White & Blue K418 Instructions for Use

Please read and retain these instructions for future reference

Step 2: Remove the exhausted battery and install 1x new AA rechargeable battery according to the +/polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step 3: Replace battery compartment cover, screw it back into position and make sure is properly sealed. Step 4: Charge battery under direct sunlight for at least 8 hours.

#### CARE AND MAINTENANCE RECOMMENDATIONS

- 1. Clean solar panel with a soft sponge every couple of weeks.
- 2. Make sure all connectors are still tight and no water getting in.

#### BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

#### DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



v001: 24/09/21

• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	<u>ک</u>	OTHER
Type of	Polypropylene	Please Specify (includes ABS, Nylon)
Plastic		
Commonly	Microwaveable food containers, yoghurt pots,	CD's, crisp packets, various flexible packaging,
used for	butter tubs, disposable plates and cups	baby bottles, sunglass lenses
	Commonly recycled and collected from household	Not often or widely recycled
Notes	recycling bins (packaging tape itself not recyclable	
	but does not interfere with cardboard)	

 At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



The Enterprise Department Head Office: 11 Bridge Street Bishop's Stortford, CM23 2JU Tel: 0844 482 4400\* Fax: 01279 756 595 www.coopersofstortford.co.uk

\*Calls cost 7 pence per minute plus your telephone company's network access charge