

Long Reach Hair Remover

K450

v001: 03/11/21

Please read and retain these instructions for future reference

vivadia



Dimensions

(H) 54.5 x (W) 3.95 x (D) 3.1cm

Material: ABS

Batteries required: 2x 1.5V AAA (not included)


- LONG REACH EXTENSION SO YOU DON'T HAVE TO BEND
- 2 SHAVER ATTACHMENTS, NOSE HAIR TRIMMER AND HAIR REMOVER
- USE SHORT OR LONG HANDLED – 2 IN 1 FUNCTION
- MULTI-FUNCTIONAL FLEX NECK
- TOP HEAD CAN BE ANGLED TO SUIT AND ROTATED 50 DEGREES
- SOFT GRIP SILICONE HANDLE

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:


Unpack the components carefully. Please check all parts have been removed from the packaging.

Parts


- A. Cutter Head
- B. Battery Compartment
- C. Power switch
- D. Flex Neck
- E. Flex Neck Switch
- F. Handle



Long handled



Press the button to remove the flex neck and to use with short handle.



Short handled

Long Reach Hair Remover K450


Please read and retain these instructions for future reference

Instructions for Use


v001: 03/11/21

User Instructions

Use with or without Flex Neck to reach hair anywhere.



Cutter Head can be bent by 50 degrees.



The Flex Neck can be bent by 360 degrees.

Cleaning and Maintenance

- Switch trimmer off before cleaning the blade. Use a paper towel to clean the edges to remove hair or dirt.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk