

# Slate Look Cascading Water Feature

**K531** v001: 28/03/22

Please read and retain these instructions for future reference

**GAINSBOROUGH**  
Garden & Wildlife



## Dimensions

50 x30 x 70cm

Cable length: 5m

Pump: 12V/50Hz,25W

Max flow quantity of pump: 1100L/H(350g/h)

Water height of pump: 170cm

## FOR OUTDOOR USE.

**THE POWER ADAPTOR MUST BE CONNECTED WITHIN A WATERPROOF SOCKET ENCLOSURE IF CONNECTED OUTDOORS. IF NO WATERPROOF ENCLOSURE THEN MUST BE CONNECTED INDOORS.**

## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

### Safety instructions

- ALWAYS UNPLUG THE APPLIANCE FROM THE ELECTRICAL OUTLET AFTER USING AND BEFORE CLEANING.
- DO NOT DROP OR PLACE THE FEATURE IN WATER OR OTHER LIQUIDS.
- DO NOT CONNECT TO ANY VOLTAGE OTHER THAN THAT SHOWN ON THE RATING LABEL.
- NEVER COVER THE WATER FEATURE WHEN IT IS IN OPERATION.
- PLACE ON A FLAT SURFACE.
- NEVER PLACE THE WATER FEATURE ON TOP OF ANOTHER ELECTRICAL APPLIANCE.
- NEVER LET THE PUMP RUN DRY.
- USE MAINS WATER ONLY WHEN FILLING THE WATER FEATURE.

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.


# Slate Look Cascading Water Feature K531 Instructions for Use

Please read and retain these instructions for future reference

v001: 28/03/22

## ASSEMBLY INSTRUCTIONS

- Unpack all the water fountain components from the packaging and position them on a flat surface.
- Connect the pump to the rubber tube. Make sure the tube is properly connected and is not kinked.
- Connect cable connector to female cord from pump body.
- Install fountain top on the base, ensure it is stable before continuing.
- Connect pump cord to adapter.
- Insert the plug into the power socket. If installed correctly water will start to flow from the feature.



## Care and Maintenance Recommendations

**Always switch off and disconnect the plug/transformer from the electrical outlet before handling the pump.**

- Keep the fountain in good working condition by cleaning it and changing the water every 3 days.
- If debris is caught in the intake vents of the pump, disconnect the pump from any power sources and rinse the pump under clean running water.
- Make sure all connectors are still tight and no water getting in.
- Keep the water clean during the summer keep topping up every 3 or 4 days with clean water.
- Clean any pipes every month stop any build-up of algae which could put an extra pressure on your pump.
- Always make sure there is enough water for the pump to work otherwise you could damage the pump.
- Make sure you clean the pump on a regularly bases when you are cleaning face the solar panel face down on a towel this will stop the pump running or switch it off.
- During the winter if you can bring it inside and give a good clean ready for next year.

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.

# Slate Look Cascading Water Feature K531 Instructions for Use


Please read and retain these instructions for future reference

v001: 28/03/22

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PETE	 PVC	 OTHER
Type of Plastic	Polyethylene Terephthalate	Polyvinyl Chloride	ABS
Commonly used for	Soft drink and juice bottles, shampoo bottles, meat trays, fruit punnets	Pipes, construction material, flooring, windows, guttering, plaster packs	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Commonly recycled and collected from household recycling bins. Check with your local authority	Not usually collected from household recycling bins, Sometimes recycled at local waste management centres.	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

UK  
CA

CE



**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.