

# Set 6 Solar Flame Effect Stake Lights K754 Instructions for Use

Please read and retain these instructions for future reference

v001: 28/02/22

## ALWAYS POSITION IN DIRECT SUNLIGHT



### Dimensions

(H) 36.5 x (W) 5.5 x (D) 5.5cm

- 26CM HIGH NOT INCLUDING STAKE
- 36.5 CM HEIGHT TOTAL INCLUDING STAKE
- DANCING FLAME EFFECT LED LIGHT IN EACH STAKE (LEDs not replaceable)
- PERFECT FOR LIGHTING PATHS, FLOWER BEDS OR BORDERS
- AUTOMATICALLY LIGHTS UP AT DUSK
- HIGH QUALITY STAINLESS STEEL
- ADD WARMTH DEPTH AND CHARACTER TO YOUR GARDEN THIS AUTUMN, THESE STAKES PROVIDE A WELCOME GLOW THAT RESEMBLES REAL FLAMES BUT WITH THE EASE OF SOLAR POWERED LEDS.

1 X AAA 1.2V 150MAH NI-MH RECHARGEABLE BATTERY FOR EACH LIGHT INCLUDED

### ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging. Connect the top part with the spike by twisting them together.

#### Before using first time

#### CHARGING AND OPERATION:

1. There is an "on/off" switch at the back of the solar panel case. Twist the lamp shade and find the switch then push the switch to "on" position. Then replace the cover and position the light in a sunny location. Charge the solar product by placing it under direct sunlight for **at least 8 hours**.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to verify that the button is correctly in the "ON" position, cover the solar panel with your hand and light should turn "ON" automatically.

#### Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically.

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU  
Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.

# Set 6 Solar Flame Effect Stake Lights K754 Instructions for Use

Please read and retain these instructions for future reference

v001: 28/02/22

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

## Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. If solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1x AAA 1.2v 150Mah, Ni-MH, Rechargeable– Same equivalent type as recommended must be used).
4. **Battery replacement:**  
**Step1:** Unscrew the battery compartment cover by using a Phillips head screwdriver (not included) .  
**Step2:** Remove the exhausted battery and install 1x AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.  
**Step3:** Replace battery compartment cover, screw it back into position and make sure is properly sealed.  
**Step4:** Charge the solar product by placing it under direct sunlight for **at least 8 hours**.


## BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.

# Set 6 Solar Flame Effect Stake Lights K754 Instructions for Use

Please read and retain these instructions for future reference

v001: 28/02/22

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.